



Original	Recharge
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
<X>	Fav / Marker / PC
Search	Shift + Red / Netflix /
TV	TV/Radio /
Home/VOD	Shift + Menu /
Menu	Menu / Home

Original	Recharge
Vol+	Vol+
Vol-	Vol-
P+	CH+ / Page+
P-	CH- / Page-
Up	Up
Down	Down
Right	Right
Left	Left
OK	OK
Back	Back / Return
*	Smart / List
i	Info / Angle
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
<<	<< / Tune-





Original		Recharge		Original		Recharge	
	Play		Play / Slow				
	>>		>> / Tune+				
	Stop		Stop / Hold				
	Pause		Pause / Step / Freeze				
	Rec		Rec / Rec Mode				
	EPG		Guide / EPG / -/--				
	?		Subtitle / EQ				
	...♪		Sound / Title				
	A-z		Zoom / Size				
	[=]		Text / Goto				
	*		Setup / OPT /				

