



































































































Original	Recharge	Original	Recharge
 Power	 Power	 CH-	 CH- / Page-
 1	 1	 Home	 Menu / Home
 2	 2	 Source	 AV / Input / RDS
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 Wheel Up	 >> / Tune+
 6	 6	 Right	 Right
 7	 7	 OK	 OK
 8	 8	 Wheel Down	 << / Tune-
 9	 9	 Down	 Down
 List/Menu	 Guide / EPG / -/--	 *	 Setup / OPT /
 List/Menu	 Smart / List	 Back	 Back / Return
 0/Quick Access	 0	 Red	 Red / Netflix / Search
 Vol+	 Vol+	 Green	 Green / APP / Repeat
 CH+	 CH+ / Page+	 Yellow	 Yellow / YouTube / Repeat
 Mute	 Mute / Dimmer	 Blue	 Blue / Prime Video / Random
 Vol-	 Vol-	 Netflix	 Shift + Red / Netflix / Search

Original	Recharge	Original	Recharge
 CH-	 CH- / Page-	 CH PAGE	CH- / Page-
 Home	 Menu / Home	 HOME MENU	Menu / Home
 Source	 AV / Input / RDS	 RDS AV INPUT	AV / Input / RDS
 Up	 Up	 Up	Up
 Left	 Left	 Left	Left
 Wheel Up	 >> / Tune+	 TUNE+	>> / Tune+
 Right	 Right	 Right	Right
 OK	 OK	 OK	OK
 Wheel Down	 << / Tune-	 TUNE-	<< / Tune-
 Down	 Down	 Down	Down
 *	 Setup / OPT /	 OPT-TOOLS SETUP	Setup / OPT /
 Back	 Back / Return	 RETURN BACK	Back / Return
 Red	 Red / Netflix / Search	 NETFLIX SEARCH	Red / Netflix / Search
 Green	 Green / APP / Repeat	 APP REPEAT	Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat	 YouTube REPEAT A-B	Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random	 Prime Video RANDOM	Blue / Prime Video / Random
 Netflix	 Shift + Red / Netflix / Search	 SHIFT + NETFLIX SEARCH	Shift + Red / Netflix / Search





	Original	Recharge		Original	Recharge
	prime video	+ RANDOM	Shift + Blue / Prime		
	Disney+	+ REPEAT	Shift + Green / APP /		
	Rakuten TV	+ REPEAT A-B	Shift + Yellow / YouTube /		

