



Original	Recharge
Power	Power
Mute	Mute / Dimmer
Preset/Folder Up	CH+ / Page+
Vol+	Vol+
Preset/Folder	CH- / Page-
Function	Menu / Home
Vol-	Vol-
Sleep	Sleep / Timer
Play	Play / Slow
Pause	Pause / Step / Freeze
Tun-/l<</<<	<< / Tune-
Stop	Stop / Hold
>>/>>I/Tuner+	>> / Tune+
Repeat	Green / APP / Repeat
Program/Memo	TV/Radio /
RDS	AV / Input / RDS
PTY	Picture / Format

Original	Recharge
PTY Search	Red / Netflix / Search
EQ	Subtitle / EQ
XDSS Plus	Audio / Lang I/II
1	1
2	2
3	3
4	4
5	5
6	6
MP3 Info	Info / Angle
7	7
8	8
9	9
0	0

