



















































	Original	Recharge	Original	Recharge
	Power			>>
	USB			Flat
	HDMI ARC			Vol-
	OPTICAL			Vol-
	BT			Mute
	COAXIAL			TV
	AUX 1			CINEMA
	AUX 1			SONG
	AUX 2			
	Vol+			
	Vol+			
	I<<			
	I<<			
	Play/Pause / Pair			
	Play/Pause / Pair			
	Play/Pause / Pair			
	>>			
				Right
				Smart / List
				Vol-
				Down
				Mute / Dimmer
				Red / Netflix / Search
				Green / APP / Repeat
				Yellow / YouTube / Repeat

