



































































































Original	Rechange
 Power	 Power
 Source	 AV / Input / RDS
 Text	 Text / Goto
 T.Opt	 Setup / OPT /
 AD	 Audio / Lang I/II
 *	 Menu / Home
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0

Original	Rechange
 ...	 Fav / Marker / PC
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Search	 Display / Media
 CH-	 CH- / Page-
 TV	 TV/Radio /
 Netflix	 Shift + Red / Netflix /
 Home	 Shift + Menu /
 prime video	 Shift + Blue / Prime
 Disney+	 Shift + Yellow / YouTube /
 Up	 Up
 Movies	 Shift + Green / APP /
 Left	 Left
 OK	 OK
 Right	 Right





Original		Recharge		Original		Recharge	
	Back		Back / Return				
	Down		Down				
	[→]		Exit / Cancel / Clear				
	Guide		Guide / EPG / -/--				
	Rec		Rec / Rec Mode				
	Stop		Stop / Hold				
	<<		<< / Tune-				
	Play		Play / Slow				
	Pause		Pause / Step / Freeze				
	>>		>> / Tune+				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				

