







































































Original	Rechange	Original	Rechange
	Power		Power
	<<		<< / Tune-
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	: =		D.Menu / Top
	Smart		Smart / List
	Input		AV / Input / RDS
	←		Back / Return
	Home		Menu / Home
	[ ]		TV/Radio /
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Vol+		Vol+
	CH+		CH+ / Page+
	Mute		Mute / Dimmer
	EPG		Guide / EPG / -/-
	Vol-		Vol-
	CH-		CH- / Page-
	Netflix		Shift + Red / Netflix /
	prime video		Shift + Blue / Prime
	YouTube		Shift + Yellow / YouTube /
	Google Play		Shift + 2
	Disney+		Shift + Green / APP /
	Spotify		Display / Media
	..OQ		Picture / Format
	Eco		Setup / OPT /
	(i)		Info / Angle
	1		1





Original		Rechange		Original		Rechange	
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
TXT	TXT	GOTO TEXT	Text / Goto				
0	0	HDMI - SAT 0	0				
SUB	SUB	EQ SUBTITLE	Subtitle / EQ				
Red	Red	NETFLIX SEARCH	Red / Netflix / Search				
Green	Green	APP REPEAT	Green / APP / Repeat				
Yellow	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
Blue	Blue	Prime Video RANDOM	Blue / Prime Video / Random				

