












































































Original	Recharge
 Input	 AV / Input / RDS
 Power	 Power
 VCR	 Shift + 4
 DVD	 Shift + 2
 AMP	 Shift + 5
 AUX	 Shift + 7
 [12]	 Picture / Format
 [> <]	 Shift + Zoom /
 [...]	 Subtitle / EQ
 Red/Rec/Movie	 Red / Netflix / Search
 Green/<</Sport	 Green / APP / Repeat
 Yellow/Stop/Child	 Yellow / YouTube / Repeat
 Blue/Play/News	 Blue / Prime Video / Random
 >>/Pixel Plus	 >> / Tune+
 Guide	 Guide / EPG / -/--
 Up	 Up
 [=]	 Text / Goto


Original	Recharge
 Left	 Left
 Right	 Right
 OK	 OK
 Down	 Down
 Menu	 Menu / Home
 Vol+	 Vol+
 P+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7







































































	Original	Rechange	Original	Rechange
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P	 Fav / Marker / PC		
	♪ Smart	 Sound / Title		
	[-o-]/Active Control	 D.Menu / Top		
	[ ] Smart	 Smart / List		
	[o]	 TV/Radio /		
	Setup	 Setup / OPT /		
	[+]	 Display / Media		
	[♦]/Zoom	 Zoom / Size		
	[ ]	 Audio / Lang I/II		
	Instant	 Back / Return		
	[<>]	 Sleep / Timer		
	[↔]	 Eject / Surround		








































Original	Recharge
 Input	 AV / Input / RDS
 Power	 Power
 VCR	 Shift + 4
 DVD	 Shift + 2
 AMP	 Shift + 5
 AUX	 Shift + 7
 [ > < ]	 Zoom / Size
 [ ... ]	 Subtitle / EQ
 Red/Rec/Movie	 Red / Netflix / Search
 Green/Left/Sport	 Green / APP / Repeat
 Yellow/Stop/Child	 Yellow / YouTube / Repeat
 Blue/Play/News	 Blue / Prime Video / Random
 >>/Pixel Plus	 >> / Tune+
 Guide	 Guide / EPG / -/-
 Up	 Up
 [=]	 Text / Goto
 Left	 Left






























Original	Recharge
 Right	 Right
 OK	 OK
 Down	 Down
 Menu	 Menu / Home
 Vol+	 Vol+
 P+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8








Original	Recharge
 Input	 AV / Input / RDS
 Power	 Power
 VCR	 Shift + 4
 DVD	 Shift + 2
 AMP	 Shift + 5
 AUX	 Shift + 7
 [ > < ]	 Zoom / Size
 [ ... ]	 Subtitle / EQ
 Red/Rec/Movie	 Red / Netflix / Search
 Green/Left/Sport	 Green / APP / Repeat
 Yellow/Stop/Child	 Yellow / YouTube / Repeat
 Blue/Play/News	 Blue / Prime Video / Random
 >>/Pixel Plus	 >> / Tune+
 Guide	 Guide / EPG / -/-
 Up	 Up
 [=]	 Text / Goto
 Left	 Left


Original	Recharge
 Right	 Right
 OK	 OK
 Down	 Down
 Menu	 Menu / Home
 Vol+	 Vol+
 P+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





	Original	Rechange	Original	Rechange
	9	9		
	[i+]	Info / Angle		
	0	0		
	P<P	Fav / Marker / PC		





	Original	Rechange	Original	Rechange
	Input	AV / Input / RDS		Vol+
	Power	Power		CH+ / Page+
	VCR	Shift + 4		Vol-
	DVD	Shift + 2		Mute / Dimmer
	AMP	Shift + 5		CH- / Page-
	AUX	Shift + 7		1
	[...]	Subtitle / EQ		2
	Green/<</Sport	Green / APP / Repeat		3
	>>/Pixel Plus	>> / Tune+		4
	Guide	Guide / EPG / -/--		5
	Up	Up		6
	[=]	Text / Goto		7
	Left	Left		8
	Right	Right		9
	OK	OK		0
	Down	Down		P<P
	Menu	Menu / Home		Fav / Marker / PC

