






























Original	Rechange
	1
	3
	Power
	2
	4
	5
	6
	+ Shift + Power
	7
	8
	9
	Sleep / Timer
	Guide / EPG / -/-
	+ Shift + Back / Return
	0
	+ Shift + Exit / Cancel / Clear
	Fav / Marker / PC

Original	Rechange
	Page
	Dimmer
	Progressive
	Mic Mix
	Zoom
	Echo
	Angle
	Reserve
	Play Mode
	Audio
	Karaoke
	Subtitle
	VFP
	Key b
	Key #
	Repeat
	Top Menu
+	Shift + Fav / Marker / PC
+	Shift + Mute / Dimmer
	Exit / Cancel / Clear
+	Shift + Smart / List
	Zoom / Size
+	Shift + Zoom /
	Info / Angle
	AV / Input / RDS
	Back / Return
	Audio / Lang I/II
	Eject / Surround
	Subtitle / EQ
	TV/Radio /
+	Shift + Subtitle / EQ
+	Shift + Setup / OPT / Tools
	Green / APP / Repeat
	D.Menu / Top





Original	Recharge
 Up	 Up
 Tv/Video	 Shift + TV/Radio / Program
 Menu	 Menu / Home
 Left	 Left
 Tv Channel-	 Shift + CH- /
 Enter	 OK
 Tv Channel+	 Shift + CH+ /
 Right	 Right
 Set Up	 Setup / OPT /
 Down	 Down
 On Screen	 Display / Media
 FM/AM	 Red / Netflix / Search
 FM Mode	 Smart / List
 Play/Tape A	 Shift + Play /
 <> Tape B	 Yellow / YouTube / Repeat
 Play DVD/CD	 Play / Slow
 AUX	 Shift + 7

Original	Recharge
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 I<</Prev	 I<< / Preset-
 I<< Group Skip	 Shift + Left
 >>I/Next	 >>I / Preset+
 >>I Group Skip	 Shift + Right
 <</Slow-	 << / Tune-
 >>/Slow+	 >> / Tune+
 Active Bass Extension +	 CH+ / Page+
 3D Phonic	 Picture / Format
 Sound Mode	 Sound / Title
 Active Bass Extension -	 CH- / Page-
 DVD Level	 Shift + Display / Media
 Rhythm AX	 Text / Goto
 Fade Muting	 Mute / Dimmer
 Vol-	 Vol-
 Tv Vol-	 Shift + Down





Original	Recharge
 Vol+	 Vol+
 Tv Vol+	 Shift + Up

Original	Recharge

