



Original	Recharge	Original	Recharge
 Power	 Power	 Blue	 Blue / Prime Video / Random
 Input	 AV / Input / RDS	 Profile	 D.Menu / Top
 1	 1	 *	 Setup / OPT /
 2	 2	 Up	 Up
 3	 3	 Left	 Left
 4	 4	 OK	 OK
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 ←	 Back / Return
 8	 8	 Guide	 Guide / EPG / -/--
 9	 9	 Home	 Menu / Home
 Text	 Text / Goto	 Vol+	 Vol+
 0	 0	 Mute	 Mute / Dimmer
 Sub	 Subtitle / EQ	 P+	 CH+ / Page+
 Red	 Red / Netflix / Search	 Vol-	 Vol-
 Green	 Green / APP / Repeat	 P-	 CH- / Page-
 Yellow	 Yellow / YouTube / Repeat	 YouTube	 Shift + Yellow / YouTube / Repeat



