





































| Original | Recharge | Original | Recharge |
|---|--|---|--|
|  Power STB |  Power |  Left |  Left |
|  << |  << |  OK |  Ok |
|  Play |  Play |  Right |  Right |
|  Pause |  Pause |  Down |  Down |
|  >> |  >> |  Back |  Back |
|  < |  << |  Guide |  Guide |
|  > |  >> |  X |  Exit |
|  Stop |  Stop |  Vol+ |  Vol + |
|  Rec |  Rec |  Vol- |  Vol - |
|  Red |  Red |  ↑ |  Shift + Up |
|  Green |  Green |  ↓ |  Shift + Down |
|  Yellow |  Yellow |  CH+ |  Ch + |
|  Blue |  Blue |  CH- |  Ch - |
|  Video |  Format |  Mute |  Mute |
|  Menu |  Menu |  P < P |  Pre Ch |
|  i |  Info |  1 |  1 |
|  Up |  Up |  2 |  2 |







































| Original | Recharge | Original | Recharge |
|-------------|---|-----------|--|
| PWR On/Off |  Power | Audio |  Dual |
| Epg |  Guide | CH/Page- |  Ch - |
| Subt.List |  Subt | 1. ? |  1 |
| Opt? |  Options | 2abc |  2 |
| App |  Media | 3def |  3 |
| Sleep Timer |  Sleep | 4ghi |  4 |
| TV |  TV/R | 5jkl |  5 |
| Text |  Text | 6mno |  6 |
| Zoom |  Eject | 7pqrm |  7 |
| Menu |  Menu | 8tuv |  8 |
| Menu Up |  Up | 9wxyz |  9 |
| Menu Left |  Left | 0/10 |  0 |
| OK Enter |  Ok | FAV Pref. |  Pre Ch |
| Menu Right |  Right | Red |  Red |
| Menu Down |  Down | Green |  Green |
| Back |  Back | Yellow |  Yellow |
| CH/Page+ |  Ch + | Blue |  Blue |





| Original | Recharge | Original | Recharge |
|--------------|---|----------|----------|
| PWR On/Off |  | Power | |
| Mute |  | Mute | |
| Opt? |  | Options | |
| App |  | Media | |
| Subt.List |  | Subt | |
| Info |  | Info | |
| Video |  | D. Menu | |
| Zoom |  | Eject | |
| Menu |  | Menu | |
| Menu Up |  | Up | |
| Menu Left |  | Left | |
| OK Enter |  | Ok | |
| Menu Right |  | Right | |
| Exit |  | Exit | |
| Menu Down |  | Down | |
| Back |  | Back | |
| Volume+ |  | Vol + | |
| CH/Page+ |  | Ch + | |
| Volume- |  | Vol - | |
| Audio |  | Dual | |
| CH/Page- |  | Ch - | |
| 1. ? |  | 1 | |
| 2abc |  | 2 | |
| 3def |  | 3 | |
| 4ghi |  | 4 | |
| 5jkl |  | 5 | |
| 6mno |  | 6 | |
| 7pqrm |  | 7 | |
| 8tuv |  | 8 | |
| 9wxyz |  | 9 | |
| Guide Pilote |  | Guide | |
| 0/10 |  | 0 | |
| FAV Pref. |  | Pre Ch | |
| Red |  | Red | |





| Original | Recharge | Original | Recharge |
|---------------|--|----------|----------|
| Green |  B | Green | |
| Yellow |  C | Yellow | |
| Blue |  D | Blue | |
| Dev |  LIST | List | |
| West |  I<< | I<< | |
| Dec/Pause |  II | Pause | |
| |  Shift + Ch + | | |
| |  Shift + Ch - | | |
| Freeze |  ■ | Stop | |
| East |  >>I | >>I | |
| LNB F.Forward |  >> | >> | |
| Lang./Rewind |  << | << | |
| H/V Play |  ▶ | Play | |
| | | | |
| | | | |
| | | | |
| | | | |

