




















































| Original     | Recharge  | Original   | Recharge  |
|--------------|---|------------|---|
| On/Off       |  Power   | OK Enter   |  Ok      |
| Audio Off    |  Mute  | Menu Right |  Right   |
| Slow Down    |  Ch -  | Return     |  Back    |
| Stop         |  Stop  | Menu Down  |  Down    |
| Slow Up      |  Ch +  | Progr.     |  Sleep   |
| Auto/Track   |  Smart   | Volume+    |  Vol +   |
| Pause        |  Pause   | Next       |  >>      |
| Subt.        |  Subt  | Top Menu   |  D. Menu |
| Rep/A-B      |  +  Shift + Text    | Volume-    |  Vol -   |
| Title        |  List  | 1          |  1       |
| Zoom         |  +  Shift + Eject | Prev.      |   <<    |
| Repeat/1/All |  Text  | 2          |  2     |
| DVD/TV       |  AV  | 3          |  3     |
| Menu         |  Menu  | 4          |  4     |
| Menu Up      |  Up  | 5          |  5     |
| Display      |  Info  | 6          |  6     |
| Menu Left    |  Left  | 7          |  7     |



| Original    | Recharge   | Original | Recharge |
|-------------|--|----------|----------|
| Setup       |  Options  |          |          |
| 8           |  8        |          |          |
| Record      |  Rec      |          |          |
| F.Forward   |  >>       |          |          |
| Angle       |  Format   |          |          |
| Play        |  Play     |          |          |
| Remain      |  Media    |          |          |
| Clear/00:00 |  Exit     |          |          |
| Audio       |  Dual     |          |          |
| Rewind      |  <<       |          |          |
| 9           |  9      |          |          |
| +10         |  Guide  |          |          |
| 0           |  0      |          |          |
| C/CH        |  Pre Ch |          |          |
| Open/Close  |  Eject  |          |          |
|             |  |          |          |
|             |  |          |          |

