



















Original	Recharge
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Recharge

