







































































Original		Rechange		Original		Rechange	
	i		Info / Angle		Home		Shift + Menu /
	Power		Power		Home		Smart / List
	Aa		Text / Goto		Back		Back / Return
	Lang		Audio / Lang I/II		Menu		Menu / Home
	DVD		Shift + 2		Zoom		Zoom / Size
	Open / Close		Eject / Surround		Option		Setup / OPT /
	1		1		Up / CH+		Up
	2		2		Up / CH+		CH+ / Page+
	3		3		Left		Left
	4		4		OK		OK
	5		5		Right		Right
	6		6		Down / CH-		Down
	7		7		Down / CH-		CH- / Page-
	8		8		Vol+		Vol+
	9		9		Mute		Mute / Dimmer
	Thumb Up		Display / Media		DTV		TV/Radio /
	0		0		Vol-		Vol-





Original	Recharge	Original	Recharge
	Shift + Blue / Prime		
	Guide / EPG / -/--		
	Rec / Rec Mode		
	<< / Tune-		
	Play / Slow		
	Pause / Step / Freeze		
	>> / Tune+		
	Shift + Play /		
	I<< / Preset-		
	Stop / Hold		
	>>I / Preset+		
	Red / Netflix / Search		
	Green / APP / Repeat		
	Yellow / YouTube / Repeat		
	Blue / Prime Video / Random		

