



Original		Rechange	
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	Recall		Back
	Game		Media
	Auto		Smart
	Info		Info

Original		Rechange	
	Menu		Menu
	EPG		Guide
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Zoom		Eject





Original	Rechange	Original	Rechange
 Lan/Audio	 Dual		
 Play	 Play		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		
 Text	 Text		
 Tv/Radio	 TV/R		
 Subtitle	 Subt		

