







































































Original		Rechange		Original		Rechange	
	Power		Power		TV		TV/R
	Mute		Mute		AV		AV
	Vol+		Vol +		Scart		Smart
	Vol-		Vol -		PC		Media
	CH+		Ch +		Sleep		Sleep
	CH-		Ch -		Display		Info
	1		1		Menu		Menu
	2		2		Enter		Pre Ch
	3		3		MPX		Guide
	4		4		Up		Up
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Right		Right
	8		8		Down		Down
	9		9		Index		Options
	0		0		Subtitle		Subt
	Recall		Back		Reveal		3D



