



Original	Recharge
Power	Power
Blue/3D	Shift + Power
Yellow/Source	Source
Setup/Media	Enter
Green/Mode	Auto
Hide	Mode
Zoom	Volt / Focus
Ratio	Eco / Aspect
Freeze	Freeze / Timer
Left	Left
Keystone Up	Shift + Up
Up	Up
Right	Right
Menu	Menu
Keystone Down	Shift + Down
Down	Down
1/Left/Right	Shift + Vol + / Page +

Original	Recharge
2/Stop/Back	- / Stop
3/Play/Pause/Enter	+ / Play
PgUp/Right/Left/Right/Left	Vol + / Page +
4/VGA	Shift + Vol - / Page -
5/Component	Comp / Video
6/Video	Shift + Comp / Video
PgDn/S-Video	Vol - / Page -
7/SD/USB A	Help / Info
8/HDMI/MHL	Blank / Mute
9/LAN/WiFi	3D / Invert
0/USB B	Shift + 3D / 3D /

