





































































	Original	Rechange		Original	Rechange
	Power		Power		>> /Subpage
	Source		AV		Menu
	Red		Red		Exit
	Green		Green		Up
	Yellow		Yellow		Down
	Blue		Blue		Right
	e		Media		Left
	Mouse		Options		Enter
	Home		Smart		Play
	TXT		Text		Pause
	Mix/FAV.List		List		Stop
	Size/Subtitle		Format		Vol +
	Cancel/Audio		Dual		Vol -
	↔/Refresh		Pre Ch		Mute
	<</Index		<<		Ch +
	>>/Hold		>>		Ch -
	<</Reveal		<<		Tv/Radio





Original		Recharge		Original		Recharge	
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	[*]/Display		Info				
	Recall		Back				

