





























































































Original		Recharge		Original		Recharge	
	Power		Power		→ ←		Smart / List
	Mute		Mute / Dimmer		P+		CH+ / Page+
	1		1		P-		CH- / Page-
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Vol+		Vol+
	7		7		Vol-		Vol-
	8		8		Info		Info / Angle
	9		9		Timer		Sleep / Timer
	0		0		Syst		Setup / OPT /
	AV		AV / Input / RDS		Store		Zoom / Size
	-/--		Guide / EPG / -/--		Menu		Menu / Home
	Tv		TV/Radio /		P100		Fav / Marker / PC
	TX		Text / Goto		Red		Red / Netflix / Search
	Sel		OK		Green		Green / APP / Repeat





Original	Recharge
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Clock/Sub	 Subtitle / EQ
 Update	 Back / Return
 Mix	 Picture / Format
 Double	 D.Menu / Top
 Reveal	 Display / Media
 Hold	 Stop / Hold
 Stereo On/Off	 Audio / Lang I/II
 A-B Mono	 Sound / Title
 PS ↔	 Exit / Cancel / Clear

Original	Recharge

