







































































Original		Rechange		Original		Rechange	
	Standby		Power		Subtitle		Subtitle / EQ
	Open/Close		Eject / Surround		Setup		Setup / OPT /
	1		1		Up		Up
	2		2		Zoom		Zoom / Size
	3		3		Left		Left
	OSD		Display / Media		OK		OK
	4		4		Right		Right
	5		5		Title		Sound / Title
	6		6		Down		Down
	Audio		Audio / Lang I/II		Menu		Menu / Home
	7		7		L/R		CH+ / Page+
	8		8		Play		Play / Slow
	9		9		Pause		Pause / Step / Freeze
	Angle		Info / Angle		Vol+		Vol+
	10/0		0		Stop		Stop / Hold
	10+		Guide / EPG / -/--		Mute		Mute / Dimmer
	Goto		Text / Goto		N/P		CH- / Page-





	Original	Rechange	Original	Rechange
	Step	+	Shift + Pause / Step /	
	Slow	+	Shift + Play /	
	Vol-		Vol-	
	Repeat		Green / APP / Repeat	
	A-B		Yellow / YouTube / Repeat	
	Prog		TV/Radio /	
	Return		Back / Return	
	<<		<< / Tune-	
	>>		>> / Tune+	
	Clear		Exit / Cancel / Clear	
	DVD/USB		AV / Input / RDS	
	I<<		I<< / Preset-	
	>>I		>>I / Preset+	
	RAN		Blue / Prime Video / Random	
	PBC		Smart / List	

