























	Original	Recharge	Original	Recharge
	Power			
AUX	AUX			
1	1			
2	2			
3	3			
4	4			
5	5			
6	6			
	Vol+			
	Vol-			
	Play			
	Pause			
	I<<			
	>>I	