







































































Original	Recharge	Original	Recharge
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Display		Info
	Recall		Pre Ch
	Setup		Options
	EPG		Guide
	Source		AV
	CH.List		List
	Exit/Cancel		Exit
	FAV		Shift + Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	CH+/Page+		Ch +
	CH-/Page-		Ch -
	S.Mode		Shift + Dual
	P.Mode		Format
	Vol+		Vol +
	Vol-		Vol -
	Record		Rec
	Record List		Smart
	Audio		Dual





Original		Rechange		Original		Rechange	
	S.Title/Subtitle		Subt		Hold/Title		Back
	Reveal		Menu		Zoom-		Shift + Down
	Index		3D		Size/Zoom+		Shift + Up
	Mix		Shift + Subt		Eject		Eject
	Text		Text		Sleep		Sleep
	Play		Play		Scaler		Media
	Pause		Pause		Tv/Radio		TV/R
	Stop		Stop				
	<<		<<				
	>>		>>				
	I<<		I<<				
	>>I		>>I				
	Red/Goto		Red				
	Green/A-B		Green				
	Yellow/Repeat		Yellow				
	Blue/Angle		Blue				
	S.Page/DVD		D. Menu				

