

































































Original	Recharge
 Power	 Power
 Eject	 Eject / Surround
 Angle	 Info / Angle
 Repeat	 Shift + Green / APP / REPEAT
 Q-Play	 D.Menu / Top
 Search	 Shift + Red / Netflix / SEARCH
 1	 1
 2	 2
 3	 3
 List/PBC	 Smart / List
 4	 4
 5	 5
 6	 6
 Zoom	 Zoom / Size
 7	 7
 8	 8
 9	 9

Original	Recharge
 0	 0
 Setup	 Setup / OPT /
 Up	 Up
 CH+	 CH+ / Page+
 Return	 Back / Return
 Left	 Left
 Enter	 OK
 Right	 Right
 PgUp/Title	 Sound / Title
 CH-	 CH- / Page-
 Down	 Down
 PgDn/Menu	 Menu / Home
 EPG/P/N	 Guide / EPG / -/-
 Exit/Slow	 Exit / Cancel / Clear
 Info/Display	 Display / Media
 Vol+	 Vol+
 Vol-	 Vol-





	Original	Recharge
	Tv/Radio	 TV/Radio /
	TTX	 Text / Goto
	FAV/A-B	 Fav / Marker / PC
	Audio	 Audio / Lang I/II
	Subtitle	 Subtitle / EQ
	Mute	 Mute / Dimmer
	Play	 Play / Slow
	Pause	 Pause / Step / Freeze
	Stop	 Stop / Hold
	Red	 Red / Netflix / Search
	I<<	 I<< / Preset-
	>>I	 >>I / Preset+
	Green	 Green / APP / Repeat
	Yellow	 Yellow / YouTube / Repeat
	<<	 << / Tune-
	>>	 >> / Tune+
	Blue	 Blue / Prime Video / Random

	Original	Recharge
	Video	 Shift + 4
	USB	 Shift + 8
	DVD/DVB	 Shift + 2
	Random	 Shift + Blue / Prime

