







































































| Original | Recharge | Original | Recharge |
|---|------------|---|----------|
|  | Power |  | Power |
|  | Info |  | Info |
|  | Setup |  | Options |
|  | Mute |  | Mute |
|  | Menu |  | Menu |
|  | Music |  | Media |
|  | Copy |  | Exit |
|  | Zoom |  | Eject |
|  | Tv System |  | TV/R |
|  | Source |  | AV |
|  | Vol- |  | Vol - |
|  | Vol+ |  | Vol + |
|  | Home |  | Smart |
|  | Return/X |  | Back |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Time Shift |  | Ch + |
|  | Goto |  | Ch - |
|  | Rec |  | Rec |
|  | Play |  | Play |
|  | Stop |  | Stop |





| Original | | Recharge | | Original | | Recharge | |
|----------|------------|----------|--------------|----------|------------|----------|--------------|
| | Timer | | Sleep | | Yellow/TTX | + | Shift + Text |
| | Timer | + | Shift + AV | | Blue | | Blue |
| | Pause | | Pause | | | | |
| | Slow/l> | + | Shift + Play | | | | |
| | l<< | | l<< | | | | |
| | Reclist | | List | | | | |
| | << | | << | | | | |
| | >> | | >> | | | | |
| | >>l | | >>l | | | | |
| | A-B | | D. Menu | | | | |
| | Subtitle | | Subt | | | | |
| | Repeat | | Text | | | | |
| | Audio | | Dual | | | | |
| | Red | | Red | | | | |
| | Green/EPG | | Green | | | | |
| | Green/EPG | | Guide | | | | |
| | Yellow/TTX | | Yellow | | | | |

