



Original		Rechange		Original		Rechange	
	Power		Power		Vol +		Vol +
	Source		AV		Vol -		Vol -
	Display		Info		Mute		Mute
	Freeze		Pause		CH +		Ch +
	Sleep		Sleep		CH -		Ch -
	On / Off		Text		Pic Mode		Format
	Mix		Shift + Text		I/II		Dual
	Index		List		Sound Sys		Shift + Dual
	Size		Eject		Up		Up
	Reveal		Media		Right		Right
	Update		Smart		Down		Down
	Subpage		Subt		Left		Left
	Hold		Stop		Menu		Menu
	Red		Red		1		1
	Green		Green		Menu		Ok
	Yellow		Yellow		2		2
	Blue		Blue		3		3





	Original	Rechange	Original	Rechange
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Recall			
	--/			

