



Original	Recharge
Power	Power
A-B	3D
Clear	Exit
Open/Close	Eject
Time	AV
Resume	Info
Prog	Sleep
Audio	Dual
Subtitle	Subt
Zoom	Shift + Eject
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Original	Recharge
8	8
9	9
0/10	0
10+	Guide
Ran	TV/R
OSD	Format
Return	Back
Repeat	Text
Slow	Green
Menu	Menu
Angle	Red
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Surround	Yellow
L/R	Smart
Setup	Options





Original	Recharge	Original	Recharge
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 Enter	 Ok		
 Stop	 Stop		
 Play	 Play		
 I<<	 I<<		
 >>I	 >>I		
 N/P	 Media		
 <<	 <<		
 >>	 >>		
 Pause/Step	 Pause		
 PBC	 D. Menu		
 Title	 List		

