







































































































Original		Rechange		Original		Rechange	
	Power		Power		P/Pg-		Ch -
	Mute		Mute		Menu		Menu
	Tv/Rad		TV/R		Exit		Exit
	Camera		Media		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		OK		Ok
	7		7		v--		Smart
	8		8		i		Info
	9		9		[+]		Format
	0		0		♪		Dual
	-/--/EPG		Guide		[v]		AV
	RCL		3D		FAV		Pre Ch
	P/Pg+		Ch +		Red		Red





Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--/EPG	 Guide
 RCL	 3D
 P/Pg+	 Ch +
 P/Pg-	 Ch -
 Menu	 Menu

Original	Rechange
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 [↔]	 Back
 [...]	 Subt
 [≡]	 Text

