

















Original	Rechange	Original	Rechange
 Power	 Power	 Up	 Up
 Source	 AV	 Left	 Left
 Rec	 Rec	 OK	 Ok
 APP	 Media	 Right	 Right
 <<	 <<	 Down	 Down
 Play / Pause	 Play	 EPG	 Guide
 Play / Pause	 Pause	 Back	 Back
 >>	 >>	 Vol+	 Vol +
 I<<	 I<<	 Vol-	 Vol -
 Stop	 Stop	 Info	 Info
 >>I	 >>I	 Mute	 Mute
 Red	 Red	 Prog+	 Ch +
 Green	 Green	 Prog-	 Ch -
 Yellow	 Yellow	 1	 1
 Blue	 Blue	 2	 2
 Menu	 Menu	 3	 3
 Exit	 Exit	 4	 4



















































Original		Rechange		Original		Rechange	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Audio		Dual				
	Sub		Subt				
	List		List				
	Text		Text				
	Rec List		Smart				





Original		Rechange		Original		Rechange	
	Power		Power		6		6
	APP		Media		7		7
	Menu		Menu		8		8
	Exit		Exit		9		9
	OK		Ok		0		0
	Back		Back		Text		Text
	Vol+		Vol +				
	Vol-		Vol -				
	Info		Info				
	Mute		Mute				
	Prog+		Ch +				
	Prog-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

