















































































































Original		Recharge		Original		Recharge	
	Power On		Power		Memory		Blue
	Power Off		Shift + Power		Search		TV/R
	1/BD		1		Input Mode		AV
	2/(SAT/CBL)		2		CH+		Ch +
	3/(DOCK)		3		CH-		Ch -
	Status		4		Sleep		Sleep
	BD		5		Audio Delay		Smart
	Tuner		6		Mute		Mute
	DVD		7		Vol+		Vol +
	DOCK		8		Vol-		Vol -
	TV		9		Menu		Menu
	Game		Guide		Return		Back
	SAT/CBL		0		CH Level		Dual
	V.AUX		Pre Ch		Surround		3D
	Band		Red		Up		Up
	Mode		Green		Down		Down
	Shift		Yellow		Left		Left





Original	Rechange	Original	Rechange
 Right	 Right	 Random Ipod	 Format
 Enter	 Ok	 I<< Ipod	 I<<
 Night	 Eject	 >>I Ipod	 >>I
 Restorer	 D. Menu		
 Tone	 Info		
 Test	 Options		
 Dimmer	 List		
 < Surround	 Shift + Left		
 > Surround	 Shift + Right		
 up Tuning	 Shift + Up		
 Down Tuning	 Shift + Down		
 Play Ipod	 Play		
 Pause Ipod	 Pause		
 Stop Ipod	 Stop		
 << Ipod	 <<		
 >> Ipod	 >>		
 Repeat Ipod	 Text		

