














| Original | | Rechange | | Original | | Rechange | |
|---|------------|---|--------------------|---|----------|---|----------------------------|
|  | Power |  | Power |  | 5 |  | 5 |
|  | -/-- TV |  | Guide / EPG / -/-- |  | 5 TV |  | Shift + 5 |
|  | TV |  | TV/Radio / |  | 6 |  | 6 |
|  | DVD |  | Smart / List |  | 6 TV |  | Shift + 6 |
|  | Open/Close |  | Eject / Surround |  | 7 |  | 7 |
|  | Mute |  | Mute / Dimmer |  | 7 TV |  | Shift + 7 |
|  | Display |  | Display / Media |  | 8 |  | 8 |
|  | PP |  | Back / Return |  | 8 TV |  | Shift + 8 |
|  | TV/AV |  | AV / Input / RDS |  | 9 TV |  | Shift + 9 |
|  | 1 |  | 1 |  | 9 |  | 9 |
|  | 1 TV |  | Shift + 1 |  | 0 TV |  | Shift + 0 |
|  | 2 |  | 2 |  | 0 |  | 0 |
|  | 2 TV |  | Shift + 2 |  | -/-- |  | Shift + Guide / EPG / -/-- |
|  | 3 |  | 3 |  | +10 |  | Fav / Marker / PC |
|  | 3 TV |  | Shift + 3 |  | Audio |  | Audio / Lang I/II |
|  | 4 |  | 4 |  | Setup |  | Setup / OPT / |
|  | 4 TV |  | Shift + 4 |  | Menu DVD |  | Menu / Home |





| Original | Rechange |
|--|---|
|  Menu Tv |  D.Menu / Top |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Up |  Up |
|  Down |  Down |
|  Left |  Left |
|  Right |  Right |
|  Enter |  OK |
|  I<< |  I<< / Preset- |
|  >>I |  >>I / Preset+ |
|  Play |  Play / Slow |
|  Pause/Step |  Pause / Step / Freeze |
|  << Scan |  << / Tune- |
|  Scan >> |  >> / Tune+ |
|  Stop |  Stop / Hold |

| Original | Rechange |
|--|---|
|  Repeat A-B |  Yellow / YouTube / Repeat |
|  Program |  Shift + TV/Radio / Program |
|  Slow |  Shift + Play / |
|  Search |  Red / Netflix / Search |
|  Zoom |  Zoom / Size |
|  Clear |  Exit / Cancel / Clear |
|  Repeat |  Green / APP / Repeat |
|  Angle |  Info / Angle |
|  Subtitle |  Subtitle / EQ |
|  PAL/NTSC |  Picture / Format |
|  ? |  Shift + Info / Angle |
|  ◆ |  Shift + Setup / OPT / Tools |
|  + |  Shift + Zoom / |
|  [><] |  Shift + Subtitle / EQ |
|  Timer |  Sleep / Timer |
|  X |  Shift + Exit / Cancel / Clear |
|  [/≡] |  Shift + Text / Goto |



