







































































	Original	Rechange		Original	Rechange
	 Power	 Power		 8	 8
	 Mute	 Mute		 9	 9
	 Audio	 Dual		 0	 0
	 N/P	 Format		 10+	 Guide
	 Subtitle	 Subt		 Setup	 Options
	 Zoom	 Eject		 Up	 Up
	 Angle	 Back		 Down	 Down
	 Program	 Sleep		 Right	 Right
	 Display	 Info		 Left	 Left
	 Step	 AV		 Enter	 Ok
	 1	 1		 Repeat	 Text
	 2	 2		 AB	 TV/R
	 3	 3		 Menu	 Menu
	 4	 4		 PBC	 Pre Ch
	 5	 5		 Stop	 Stop
	 6	 6		 <<	 <<
	 7	 7		 >>	 >>



