












| Original | Rechange | Original | Rechange |
|---------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------|----------------|
|  | Power |  | Power |
|  | Sleep |  | Sleep |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Back |  | Back |
|  | Null |  | Shift + Eject |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Aspect |  | 3D |
|  | Audio |  | Dual |
|  | Display |  | Info |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Menu |  | Menu |
|  | Exit |  | Exit |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK/Enter |  | Ok |
|  | Input |  | AV |
|  | PMode |  | Shift + Format |
|  | Ch.List |  | List |
|  | SMode |  | Shift + Dual |
|  | FAV |  | Pre Ch |





| Original | Recharge |
|---------------|--------------|
| EPG | Guide |
| TV/Radio | TV/R |
| Subtitle | Subt |
| Text | Text |
| Index | Smart |
| Mix | Eject |
| Hold | Media |
| Reveal | Options |
| Subpage | Shift + Subt |
| Cancel | D. Menu |
| Size | Format |
| Rec | Rec |
| Stop | Stop |
| Play | Play |
| T-Shift/Pause | Pause |
| >> | >> |
| << | << |

| Original | Recharge |
|-------------|----------|
| >> | >> |
| << | << |
| Red | Red |
| Green | Green |
| Yellow/ (A) | Yellow |
| Blue | Blue |

