
















| Original | Rechange |
|---|--|
|  Mute |  Mute / Dimmer |
|  Power |  Power |
|  Media |  Display / Media |
|  AV |  AV / Input / RDS |
|  Freeze |  Shift + Pause / Step / |
|  Exit |  Exit / Cancel / Clear |
|  Guide |  Guide / EPG / -/-- |
|  Text |  Text / Goto |
|  Subt. |  Subtitle / EQ |
|  Format |  Picture / Format |
|  Mode |  Setup / OPT / |
|  Up |  Up |
|  Lang. |  Audio / Lang I/II |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Menu / Back |  Menu / Home |

| Original | Rechange |
|--|---|
|  Down |  Down |
|  Info |  Info / Angle |
|  PR- |  CH- / Page- |
|  PR+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Vol+ |  Vol+ |
|  Red / List / Page+ |  Red / Netflix / Search |
|  Red / List / Page+ |  Shift + CH+ / |
|  Red / List / Page+ |  Smart / List |
|  Green / Page- |  Green / APP / Repeat |
|  Green / Page- |  Shift + CH- / |
|  Yellow / Sound |  Sound / Title |
|  Yellow / Sound |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |





| | Original | Rechange | Original | Rechange |
|---|----------|---|----------|-----------------------|
|  | 4 |  | | |
|  | 5 |  | | |
|  | 6 |  | | |
|  | 7 |  | | |
|  | 8 |  | | |
|  | 9 |  | | |
|  | Fav. |  | | Fav / Marker / PC |
|  | 0 |  | | |
|  | P<P |  | | Back / Return |
|  | << |  | | << / Tune- |
|  | >> |  | | >> / Tune+ |
|  | Timers |  | | Sleep / Timer |
|  | Lib. |  | | D.Menu / Top |
|  | Play |  | | Play / Slow |
|  | Stop |  | | Stop / Hold |
|  | Pause |  | | Pause / Step / Freeze |
|  | Rec |  | | Rec / Rec Mode |

