







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol+
	e/Energy Saving		Display / Media		FAV/Mark		Fav / Marker / PC
	AV Mode		Shift + AV / Input / RDS		P+		CH+ / Page+
	Input		AV / Input / RDS		Vol-		Vol-
	Tv/Rad		TV/Radio /		Ratio		Picture / Format
	1		1		P-		CH- / Page-
	2		2		Mute		Mute / Dimmer
	3		3		Guide		Guide / EPG / -/-
	4		4		Home		Menu / Home
	5		5		Q.Menu		D.Menu / Top
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		OK
	9		9		Right		Right
	List		Smart / List		Down		Down
	0		0		Back		Back / Return
	Q.View		Zoom / Size		Info		Info / Angle





Original		Recharge	
	Exit		Exit / Cancel / Clear
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	T.Opt.		Setup / OPT /
	Subtitle		Subtitle / EQ
	Stop		Stop / Hold
	Play		Play / Slow
	Pause/Freeze		Pause / Step / Freeze
	<<		<< / Tune-
	>>		>> / Tune+
	Simplink		Shift + Smart / List
	AD		Audio / Lang I/II

Original		Recharge	

