







































































Original		Recharge		Original		Recharge	
	Power		Power		>>		>>
	Open/Close		Eject		<<		<<
	1		1		>>		>>
	2		2		<<		<<
	3		3		Disc Menu		D. Menu
	4		4		Info/Menu		Info
	5		5		Back		Back
	6		6		Home		Smart
	7		7		Title/Popup		Options
	8		8		Enter		Ok
	9		9		Up		Up
	0		0		Down		Down
	Clear		Exit		Right		Right
	Repeat		Text		Left		Left
	Play		Play		Red		Red
	Stop		Stop		Green		Green
	Pause		Pause		Yellow		Yellow



