





























































| Original | Recharge |
|--------------|----------------|
| Power | Power |
| TV / AV | AV |
| Open / Close | Eject |
| Multimedia | Media |
| List | List |
| [=] / Text | Text |
| PSM | Shift + Format |
| SSM | Shift + Dual |
| I/II / Audio | Dual |
| Stop | Stop |
| Play | Play |
| Pause / Step | Pause |
| I<< | I<< |
| >>I | >>I |
| << | << |
| >> | >> |
| >I< / Repeat | Shift + Text |

| Original | Recharge |
|------------------|----------|
| Menu | Menu |
| ARC | Back |
| Exit | Exit |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| OK | Ok |
| Red / Disc Menu | Red |
| Green / Title | Green |
| Yellow / Display | Yellow |
| Blue / Return | Blue |
| Vol + | Vol + |
| Vol - | Vol - |
| Mute | Mute |
| PR + | Ch + |
| PR - | Ch - |





| Original | Recharge | Original | Recharge |
|--|--|--|---|
|  Q.View |  Options |  Marker |  Shift + Media |
|  1 |  1 |  Search |  TV/R |
|  2 |  2 |  Program |  Shift + Sleep |
|  3 |  3 |  Zoom |  Shift + Eject |
|  4 |  4 |  [=o] / Time |  Shift + AV |
|  5 |  5 |  [= /] / Mix |  Pre Ch |
|  6 |  6 |  [=?] / Reveal |  Guide |
|  7 |  7 |  [=M] / Mode |  D. Menu |
|  8 |  8 |  [=X] / Update |  Shift + TV/R |
|  9 |  9 |  [=♦] / Size |  Format |
|  0 |  0 |  [=+] / Hold |  Shift + Subt |
|  Sleep |  Sleep |  [=i] / Index |  Info |
|  Clear |  Shift + Exit | | |
|  A-B |  3D | | |
|  Random |  Smart | | |
|  Angle |  Shift + Info | | |
|  Sub.T |  Subt | | |

| Original | Recharge | Original | Recharge |
|--|---|--|---|
|  Marker |  Shift + Media |  Marker |  Shift + Media |
|  Search |  TV/R |  Search |  TV/R |
|  Program |  Shift + Sleep |  Program |  Shift + Sleep |
|  Zoom |  Shift + Eject |  Zoom |  Shift + Eject |
|  [=o] / Time |  Shift + AV |  [=o] / Time |  Shift + AV |
|  [= /] / Mix |  Pre Ch |  [= /] / Mix |  Pre Ch |
|  [=?] / Reveal |  Guide |  [=?] / Reveal |  Guide |
|  [=M] / Mode |  D. Menu |  [=M] / Mode |  D. Menu |
|  [=X] / Update |  Shift + TV/R |  [=X] / Update |  Shift + TV/R |
|  [=♦] / Size |  Format |  [=♦] / Size |  Format |
|  [=+] / Hold |  Shift + Subt |  [=+] / Hold |  Shift + Subt |
|  [=i] / Index |  Info |  [=i] / Index |  Info |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

