

























































	Original	Recharge	Original	Recharge
	Power			I<< Skip
	PIP Audio			Skip >>I
	PIP			Pause
	Open/Close			Play
	1			Stop
	2			Home
	3			Disc menu
	4			Return
	5			Display
	6			Up
	7			Down
	8			Right
	9			Left
	0			Enter
	Clear			Audio
	<< Scan			Subtitle
	Scan >>			On-Off
				Dual
				Subt
				Media





Original		Recharge	
	Title/Pop-Up		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Marker		Pre Ch
	Search		TV/R
	Repeat		Text
	Zoom		Shift + Eject
	Tv Power		Shift + Power
	AV/Input Tv		AV
	PR/CH+ Tv		Ch +
	PR/CH- Tv		Ch -
	Vol+ Tv		Vol +
	Vol- Tv		Vol -
	Tv Mute		Mute
	Resolution		Guide

Original		Recharge	
	*		List

