


































































Original	Recharge	Original	Recharge
I<<	 I<< / Preset-	 Green	 Green / APP / Repeat
>>I	 >>I / Preset+	 Yellow	 Yellow / YouTube / Repeat
 Source	 AV / Input / RDS	 Blue	 Blue / Prime Video / Random
 Power	 Power	 1	 1
 World	 Display / Media	 2	 2
 Netflix	 Shift + Red / Netflix /	 3	 3
 YouTube	 Shift + Yellow / YouTube /	 4	 4
 Music-Photo-Movi	 Setup / OPT /	 5	 5
 Rec	 Rec / Rec Mode	 6	 6
 Play	 Play / Slow	 7	 7
 Pause	 Pause / Step / Freeze	 8	 8
 Stop	 Stop / Hold	 9	 9
 Lang.	 Audio / Lang I/II	 Tv	 TV/Radio /
 <<	 << / Tune-	 0	 0
 >>	 >> / Tune+	 →←	 Zoom / Size
 Subtitle	 Subtitle / EQ	 Menu	 Menu / Home
 Red	 Red / Netflix / Search	 Q.Menu	 D.Menu / Top





Original	Recharge
Vol+	Vol+
Ch+	CH+ / Page+
Up	Up
Left	Left
Ok	OK
Right	Right
Vol-	Vol-
Down	Down
Ch-	CH- / Page-
Back	Back / Return
Exit	Exit / Cancel / Clear
→(☺)←	Guide / EPG / -/--
Fav	Fav / Marker / PC
Info	Info / Angle
Mute	Mute / Dimmer
*1/●	SHIFT + Shift + Setup / OPT / Tools
*2/Search	Sound / Title

Original	Recharge
[≡]	+ Shift + Text /
Text	Text / Goto

