











































































































































| Original | Rechange | Original | Rechange |
|---|---------------|---|----------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | TV |  | Shift + Red |
|  | SP |  | Shift + Yellow |
|  | REC |  | Shift + Green |
|  | AUDIO |  | Shift + Blue |
|  | Timer/IN-Mode |  | AV |
|  | >[]</5/7CH |  | Format |
|  | Sound |  | Dual |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0/AV |  | 0 |
|  | EPG/Bass |  | Guide |
|  | Media/Surr |  | Media |
|  | PIP/AUX |  | Pre Ch |
|  | Text |  | Text |
|  | Menu |  | Menu |
|  | End |  | Exit |
|  | Info |  | Info |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | P+ |  | Ch + |
|  | P- |  | Ch - |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |







































| Original | Recharge |
|---|--|
|  Power |  Power |
|  TV |  Shift + Red |
|  REC |  Shift + Green |
|  SP |  Shift + Yellow |
|  AUDIO |  Shift + Blue |
|  Timer/IN-Mode |  AV |
|  >[]</5/7CH |  Format |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0/AV |  0 |

| Original | Recharge |
|---|--|
|  EPG/Bass |  Guide |
|  Media/Surr |  Media |
|  PIP/AUX |  Pre Ch |
|  Text |  Text |
|  Menu |  Menu |
|  End |  Exit |
|  Info |  Info |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  Red/Music |  Red |
|  Green/Movie |  Green |
|  Yellow/Show |  Yellow |









































































| Original | Rechange |
|--|--|
|  Power |  Power |
|  TV |  Shift + Red |
|  REC |  Shift + Green |
|  SP |  Shift + Yellow |
|  AUDIO |  Shift + Blue |
|  Mute |  Mute |
|  Timer/IN-Mode |  AV |
|  >[]</5/7/CH (1) |  Format |
|  Sound |  Dual |
|  EPG/Bass (1) |  Guide |
|  Media/Surr |  Media |
|  Sound1 |  1 |
|  Sound2 |  2 |
|  Sound3 |  3 |
|  Sound4 |  4 |
|  >[]</5/7/CH (2) |  Shift + Format |
|  EPG/Bass (2) |  5 |

| Original | Rechange |
|--|---|
|  EPG/Bass (3) |  6 |
|  PIP/AUX (1) |  Pre Ch |
|  PIP/AUX (2) |  Shift + 1 |
|  PIP/AUX (3) |  Shift + 2 |
|  PIP/AUX (4) |  Shift + 3 |
|  PIP/AUX (5) |  Shift + 4 |
|  PIP/AUX (6) |  Shift + 5 |
|  PIP/AUX (7) |  Shift + 6 |
|  Text |  Text |
|  Menu |  Menu |
|  End |  Exit |
|  Info |  Info |
|  OK |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |





| Original | Recharge |
|---|--|
|  Power |  Power |
|  TV |  Shift + Red |
|  REC |  Shift + Green |
|  SP |  Shift + Yellow |
|  AUDIO |  Shift + Blue |
|  Timer/IN-Mode |  AV |
|  >[]</5/7/CH |  Format |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0/AV |  0 |

| Original | Recharge |
|---|--|
|  EPG/Bass |  Guide |
|  Media/Surr |  Media |
|  PIP/AUX |  Pre Ch |
|  Text |  Text |
|  Menu |  Menu |
|  End |  Exit |
|  Info |  Info |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  Red/Music |  Red |
|  Green/Movie |  Green |
|  Yellow/Show |  Yellow |



