







































































Original		Rechange		Original		Rechange	
	Sleep		Sleep / Timer		Vol+		Vol+
	On/Standby		Power		CH-		CH- / Page-
	CBL/SAT		0		Mute		Mute / Dimmer
	DVD		2		Vol-		Vol-
	Blu-ray		4		Info		Info / Angle
	Game		Fav / Marker / PC		Option		Shift + Setup / OPT / Tools
	AUX		7		Option		Menu / Home
	Media Player		Display / Media		Up		Up
	TV Audio		1		Left		Left
	CD		3		Enter		OK
	Tuner		6		Right		Right
	iPod/USB		8		Back		Back / Return
	Phono		Guide / EPG / -/--		Down		Down
	M-XPort		5		Setup		Setup / OPT /
	Network		9		I<</Tune-		I<< / Preset-
	Internet Radio		Smart / List		I<</Tune-		<< / Tune-
	CH+		CH+ / Page+		Play / Pause		Play / Slow









































































Original	Recharge
Play / Pause	Pause / Step / Freeze
>>I/Tune+	>> / Tune+
>>I/Tune+	>>I / Preset+
Favorite Station 1	Sound / Title
Favorite Station 2	Audio / Lang I/II
Favorite Station 3	Subtitle / EQ
Red/Movie	Red / Netflix / Search
Green/Music	Green / APP / Repeat
Blue/Game	Blue / Prime Video / Random
Yellow/Pure	Yellow / YouTube / Repeat

Original	Recharge









Original	Rechange	Original	Rechange
 Sleep	 Sleep / Timer	 Vol+	 Vol+
 On/Standby	 Power	 CH-	 CH- / Page-
 CBL/SAT	 0	 Mute	 Mute / Dimmer
 DVD	 2	 Vol-	 Vol-
 Blu-ray	 4	 Option	 Setup / OPT /
 Game	 Fav / Marker / PC	 Option	 Menu / Home
 AUX	 7	 Up	 Up
 Media Player	 Display / Media	 Left	 Left
 TV Audio	 1	 Enter	 OK
 CD	 3	 Right	 Right
 Tuner	 6	 Back	 Back / Return
 iPod/USB	 8	 Down	 Down
 Phono	 Guide / EPG / -/--	 I<</Tune-	 I<< / Preset-
 M-XPort	 5	 I<</Tune-	 << / Tune-
 Network	 9	 Play / Pause	 Play / Slow
 Internet Radio	 Smart / List	 Play / Pause	 Pause / Step / Freeze
 CH+	 CH+ / Page+	 >>I/Tune+	 >>I / Preset+





	Original	Rechange	Original	Rechange
	>> /Tune+	 >> / Tune+		
	Favorite Station 1	 Sound / Title		
	Favorite Station 2	 Audio / Lang I/II		
	Favorite Station 3	 Subtitle / EQ		

