






























































































Original	Rechange	Original	Rechange
 Power	 Power	 Blue/Title	 Blue
 Mute	 Mute	 Internet	 Smart
 Media	 Media	 []	 Subt
 *1/Display	 TV/R	 Lang	 Dual
 *2/=Q	 3D	 Size	 Format
 Exit	 Exit	 Info	 Info
 <<	 <<	 Preset	 Options
 Play	 Play	 FAV	 Shift + Pre Ch
 >>	 >>	 Sleep	 Sleep
 Pause	 Pause	 Menu	 Menu
 I<<	 I<<	 Return	 Back
 Stop	 Stop	 Source	 AV
 >>I	 >>I	 EPG	 Guide
 Rec	 Rec	 P+	 Ch +
 Red/Zoom	 Red	 P-	 Ch -
 Green/Repeat	 Green	 Vol+	 Vol +
 Yellow/Root	 Yellow	 Vol-	 Vol -





	Original	Recharge	Original	Recharge
	Up			
	Down			
	Right			
	Left			
	OK			
	1			
	2			
	3			
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	[≡]			Text
	Recall			Pre Ch

