






















































	Original	Rechange		Original	Rechange
	Standby		Power		Search
	Menu		Menu		Stop
	Title		Options		Pause
	Setup		Sleep		Repeat
	Up		Up		Zoom
	Down		Down		Slow
	Right		Right		A-B
	Left		Left		Vol+
	>>		>>		Vol-
	<<		<<		1
	>>		>>		2
	<<		<<		3
	Subtitle		Subt		4
	Angle		Guide		5
	Audio		Dual		6
	Play		Play		7
	Display		Info		8



