







































































Original		Rechange		Original		Rechange	
	Power		Power		OK		Ok
	Source		AV		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		PR+		Ch +
	5		5		PR-		Ch -
	6		6		Vol+		Vol +
	7		7		Vol-		Vol -
	8		8		Exit		Exit
	9		9		Back		Back
	0		0		Mute		Mute
	Recall		Pre Ch		i		Info
	TV		TV/R		Guide		Guide
	Menu		Menu		[≡]/Text		Text
	Q.Menu		D. Menu		Folder		Format
	World		Shift + Guide		[-O-]		Subt



