



| Original  |           | Rechange  |       | Original  |       | Rechange  |       |
|---|-----------|---|-------|---|-------|---|-------|
|    | Power     |    | Power |    | Info  |    | Info  |
|    | Mute      |    | Mute  |    | Menu  |    | Menu  |
|    | 1         |    | 1     |    | Exit  |    | Exit  |
|    | 2         |    | 2     |    | Text  |    | Text  |
|    | 3         |    | 3     |    | EPG   |    | Guide |
|    | 4         |    | 4     |    | Up    |    | Up    |
|    | 5         |    | 5     |    | Down  |    | Down  |
|    | 6         |    | 6     |    | Right |    | Right |
|    | 7         |    | 7     |    | Left  |    | Left  |
|    | 8         |    | 8     |    | OK    |    | Ok    |
|  | 9         |  | 9     |  | Stop  |  | Stop  |
|  | 0         |  | 0     |  | Play  |  | Play  |
|  | Timeshift |  | Media |  | Pause |  | Pause |
|  | Recall    |  | Back  |  | <<    |  | <<    |
|  | Mark      |  | Smart |  | >>    |  | >>    |
|  | Tv/Radio  |  | TV/R  |  | Rec   |  | Rec   |
|  | Source    |  | AV    |  | I<<   |  | I<<   |



