

























































Original	Recharge
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Back	 Back
 Audio	 Dual
 Source	 AV
 List	 List
 EPG	 Guide

Original	Recharge
 Info/[≡i]	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Recall	 Pre Ch
 Home	 Shift + Smart
 ≡	 Shift + Media
 Internet	 Media
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Radio/Audio+	 TV/R





Original		Recharge		Original		Recharge	
	Smart Tv		Smart		[≡]		Text
	On/Off Mouse		Eject		[≡+]		Shift + Subt
	Timeshift/Audio-		Shift + TV/R		[≡?]		Options
	Sleep/Zoom+		Sleep		[≡◇]/[+]		Format
	FAV/Zoom-		D. Menu		[≡x]		3D
	Red		Red		[≡o]/Subtitle		Subt
	Green		Green		Index		Shift + Info
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	>>		>>				
	l<		l<<				
	>l		>>l				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				

