



Original	Recharge
POWER	+ Shift + Power
POWER	Power
INPUT NEXT	Source
SHUT /	Video Comp / Video
ASPECT	Eco / Aspect
D. ZOOM +	+ / Play
D. ZOOM -	- / Stop
UP	Up
DOWN	Down
LEFT	Left
RIGHT	Right
ENTER	Enter
AUTO SETUP	Auto
FREEZE	Timer Freeze / Timer
USER	Mute Blank / Mute
STD	Mode

Original	Recharge

