



Original	Recharge
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Last View	Pre Ch
Radio/Tv	TV/R
Internet	Smart
Netflix	Media
Rec	Rec
Prog/Check	Sleep

Original	Recharge
Play	Play
>>	>>
<<	<<
Pause	Pause
>>	>>
<<	<<
Stop	Stop
Exit	Exit
i/Status	Info
Return	Back
Guide	Guide
Function Menu	Menu
Video Menu	D. Menu
Up	Up
Down	Down
Right	Right
Left	Left





Original		Recharge	
	OK		Ok
	Option		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Audio		Dual
	Drive Select		List
	Text		Text
	STTL		Subt
	+60s		3D
	-10s		Format
	Page/CH+		Ch +
	Page/CH-		Ch -
	Tv Vol+		Vol +
	Tv Vol-		Vol -
	AV Input Tv		AV

Original		Recharge	
	CH+ Tv		Shift + Ch +
	CH- Tv		Shift + Ch -
	Power Tv		Shift + Power

