






































































| Original   | Rechange  |
|--|---|
|  VTR                  |  Power                     |
|  Clock/Counter        |  Yellow / YouTube / Repeat |
|  Reset                |  Exit / Cancel / Clear     |
|  Memory/Repeat/Search |  Green / APP / Repeat      |
|  Audio Out            |  Mute / Dimmer             |
|  Rev.Play             |  Eject / Surround          |
|  Rec                  |  Rec / Rec Mode            |
|  Pause/Still          |  Pause / Step / Freeze     |
|  Stop                 |  Stop / Hold               |
|  Still Adv            |  >>I / Preset+             |
|  <<                  |  << / Tune-               |
|  Play               |  Play / Slow             |
|  >>                 |  >> / Tune+              |
|  Search -           |  CH- / Page-             |
|  Search             |  Red / Netflix / Search  |
|  Search +           |  CH+ / Page+             |
|  1                  |  1                       |

| Original  | Rechange  |
|---|---|
|  2           |  2                           |
|  3           |  3                           |
|  Time Search |  Blue / Prime Video / Random |
|  4           |  4                           |
|  5           |  5                           |
|  6           |  6                           |
|  Monitor     |  Display / Media             |
|  7           |  7                           |
|  8           |  8                           |
|  9           |  9                           |
|  Remain     |  Smart / List               |
|  0/AV      |  0                         |
|  0/AV      |  AV / Input / RDS          |
|  -/-       |  Guide / EPG / -/-         |
|  Index     |  Info / Angle              |
|  Write     |  Menu / Home               |
|  Erase     |  Back / Return             |

