









| Original | | Rechange | | Original | | Rechange | |
|---|------------|---|--------|---|-------------|---|--------|
|  | Standby |  | Power |  | Green/Smart |  | Green |
|  | 1 |  | 1 |  | Yellow/Lock |  | Yellow |
|  | 2 |  | 2 |  | Blue/Sleep |  | Blue |
|  | 3 |  | 3 |  | Menu |  | Menu |
|  | 4 |  | 4 |  | Teletext |  | Text |
|  | 5 |  | 5 |  | P+ |  | Ch + |
|  | 6 |  | 6 |  | P- |  | Ch - |
|  | 7 |  | 7 |  | Up |  | Up |
|  | 8 |  | 8 |  | Down |  | Down |
|  | 9 |  | 9 |  | Right |  | Right |
|  | 0 |  | 0 |  | Left |  | Left |
|  | P<P |  | Pre Ch |  | OK |  | Ok |
|  | Clear |  | Exit |  | Vol+ |  | Vol + |
|  | Mute |  | Mute |  | Vol- |  | Vol - |
|  | Record |  | Rec |  | >I/Index |  | Format |
|  | Timer |  | AV |  | >I</Still |  | 3D |
|  | Red/Select |  | Red |  | << |  | << |





| | Original | Recharge | Original | Recharge |
|---|----------|---|----------|----------|
|  | Stop |  | | |
|  | Play |  | | |
|  | >> |  | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

