











































































































































Original	Recharge	Original	Recharge
 Power	 Power	 Pause / Step	 Pause
 Open / Close	 Eject	 I<< Prev	 I<<
 Input	 AV	 >>I Next	 >>I
 DVD	 Smart	 Stop	 Stop
 VCR	 Media	 << Rew	 <<
 TV / VCR	 TV/R	 Play	 Play
 Setup	 Menu	 >> FFW	 >>
 Disc Menu	 D. Menu	 1	 1
 Up / PR/TRK +	 Up	 2	 2
 Up / PR/TRK +	 Ch +	 3	 3
 Down / PR/TRK -	 Down	 4	 4
 Down / PR/TRK -	 Ch -	 5	 5
 Right	 Right	 6	 6
 Left	 Left	 7	 7
 OK	 Ok	 8	 8
 Display	 Info	 9	 9
 Back	 Back	 0	 0





Original		Rechange		Original		Rechange	
	Power		Power		<< Rew		<<
	Open / Close		Eject		Play		Play
	Input		AV		>> FFW		>>
	DVD		Smart		1		1
	VCR		Media		2		2
	TV / VCR		TV/R		3		3
	Setup		Menu		4		4
	Up / PR/TRK +		Up		5		5
	Up / PR/TRK +		Ch +		6		6
	Down / PR/TRK -		Down		7		7
	Down / PR/TRK -		Ch -		8		8
	Right		Right		9		9
	Left		Left		0		0
	OK		Ok		Clear		Exit
	Display		Info		Marker		Pre Ch
	Pause / Step		Pause		Record		Rec
	Stop		Stop		Search		Shift + TV/R



