



















































Original		Recharge		Original		Recharge	
	Power		Power		Treble-		Ch -
	Coax		1		Sound		Dual
	Optical		3		Surround On		Smart
	Aux		4		Surround Off		Media
	Audio In		6		Audio Sync +		Right
	USB		Guide		Audio Sync -		Left
	Bluetooth		0		Night		Info
	HDMI ARC		Pre Ch		DIM		D. Menu
	I<		I<<				
	Play/Pause		Play				
	I>		I>>				
	Bass+		Up				
	Bass-		Down				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	Treble+		Ch +				

